



Installation Instructions



Install white dots stickers



Remove white dot sticker backing and dry fit PowerGate around a 50A plug. This will ensure proper alignment.



Remove face plate of pedestal and drill four screw holes through the faceplate



Insert the four screws and secure with locking nut on the back side. Finally, re-install faceplace.

Call with any questions.
Dave – 720-840-4261